

BAHRS serial protocol Version 2.0



© 2026 AMS Advanced Air Mobility Sensors UG

Table of contents

1	General information.....	4
1.1	About format.....	4
1.2	License and copyright.....	4
1.3	List of modifications.....	4
2	Protocol description.....	5
2.1	Byte order (endianness).....	5
2.2	Frame format.....	5
2.3	CRC/checksum computation.....	5
2.4	Signal health information.....	5
3	Description of messages.....	5
3.1	BAHRS inertial data output (0x01).....	5
3.2	BAHRS navigation output data (0x02).....	6
3.3	BAHRS accuracy information (0x03).....	6
3.4	Time of navigation data (0x04).....	6
3.5	Time of inertial data (0x05).....	7
3.6	Time of the latest synchronization pulse (0x06).....	7
3.7	Software version (0x0F).....	7
3.8	Hardware version (0x1F).....	7
4	Description of debug messages.....	7
5	Service messages.....	7
5.1	Request to enter diagnostics mode (0xF0).....	7
5.2	Request to exit diagnostics mode (0xF1).....	7
5.3	Request to read NVM page (0xF2).....	7
5.4	NVM page data (0xF3).....	7
5.5	Acknowledgement of diagnostics message reception (0xFF).....	8

6 Protocol versions.....	8
---------------------------------	----------

1 General information

1.1 About format

The protocol is used by the Baro-Inertial Attitude and Heading Reference System to communicate on RS232 interface.

1.2 License and copyright

This document is distributed under the Creative Commons Attribution 4.0 International Public License ([CC BY 4.0](https://creativecommons.org/licenses/by/4.0/)). This is a permissive license, so you are free to share and adapt the contents, even commercially.

The full license text is available here:

<https://creativecommons.org/licenses/by/4.0/legalcode> .

Copyright 2024 AMS Advanced Air Mobility Sensors UG

1.3 List of modifications

Date	Author	Change summary
08.04.2022	Fedor Baklanov	Initial version of the document
05.06.2022	Fedor Baklanov	Fletchers's checksum replaced by 32-bit CRC-32/MPEG-2
07.06.2022	Fedor Baklanov	Add padding to frames.
15.06.2022	Fedor Baklanov	Added 2 debug messages
21.06.2022	Fedor Baklanov	Fix byte positions in the message 0x01, 0x02, 0x03. Fixed an inconsistency in the explanation of CRC computation. Added 1 field to the accuracy data message. Changed angle scale factor in the messages 0x02 and 0x03.
16.05.2023	Fedor Baklanov	Document service messages 0xF0 to 0xF3, 0xFF
24.07.2023	Fedor Baklanov	Modified the message "BAHRS accuracy information (0x03)": attitude standard deviation D replaced by magnetic heading standard deviation. Modified the message "BAHRS navigation output data (0x02)": magnetic heading range 0 to 2 pi, type uint16_t. Rolled integer version ID.
09.09.2023	Fedor Baklanov	Cosmetic changes
21.01.2024	Fedor Baklanov	Added the message "Software version" (0x0F)
25.11.2024	Fedor Baklanov	Added the message "Hardware version" (0x1F), added health information to the messages 0x01 and 0x02 (inertial data and navigation data). Rolled integer version ID.
27.11.2024	Fedor Baklanov	Minor adjustment of scale factors for specific force and angular rate signals
01.11.2025	Fedor Baklanov	Signal validity flags replaced with integrity information bitfields

2 Protocol description

2.1 Byte order (endianness)

Least significant byte first, i. e. little-endian.

2.2 Frame format

Byte position	Data type	Description
1	uint8	Message marker 1, value 0x4E (ASCII 'N')
2	uint8	Message marker 2, value 0x45 (ASCII 'E')
3	uint16	Protocol version
4	uint8	Message type
5 to (4 + LEN)	uint8[LEN]	Payload
(5 + LEN) to (4 + LEN + PAD_LEN)	uint8[PAD_LEN]	Padding to multiple of 32-bit words, PAD_LEN = 4 – (5 + LEN) % 4
(5 + LEN + PAD_LEN) to (8 + LEN + PAD_LEN)	uint32	32-bit CRC, polynomial 0x04C11DB7, initial value 0xFFFFFFFF, input reflection = false, output reflection = false, output XOR = 0x00000000, check = 0x0376E6E7 (CRC of the char array “123456789”), name = “CRC-32/MPEG-2”

2.3 CRC/checksum computation

Bytes 1 to (4 + LEN + PAD_LEN) shall be used in cyclic redundancy check.

2.4 Signal health information

Binary value	Description
00	Signal unavailable.
01	Signal is available and safe. The signal is considered safe under the following conditions: <ul style="list-style-type: none">• Fault detection is active, and no alarms are raised.• Fault detection is active, an alarm is raised, and fault isolation is both available and successful.
10	Integrity risk. The signal is available, but may be misleading. This status occurs in the following scenarios: <ul style="list-style-type: none">• Fault detection is inactive• Fault detection is active, an alarm is raised, but fault isolation is unavailable.• Fault detection is active, an alarm is raised, fault isolation is available, but it has failed.

3 Description of messages

3.1 BAHRS inertial data output (0x01)

Byte position	Data type	Description
1	uint8	Sequence counter
2 to 3	int16	Specific force body X component
4 to 5	int16	Specific force body Y component
6 to 7	int16	Specific force body Z component
8 to 9	int16	Angular rate body X component

10 to 11	int16	Angular rate body Y component
12 to 13	int16	Angular rate body Z component
14 to 15	uint16	Signal health information (see Section 2.4). Bits 0 to 1: specific force X. Bits 2 to 3: specific force Y. Bits 4 to 5: specific force Z. Bits 6 to 7: angular rate X. Bits 8 to 9: angular rate Y Bits 10 to 11: angular rate Z. Bits 12 to 15: reserved

Specific force in $[m/s^2] = 1.4964e-3 * (\text{integer value})$.

Angular rate in $[rad/s] = 1.5979452e-4 * (\text{integer value})$.

3.2 BAHRS navigation output data (0x02)

Byte position	Data type	Description
1	uint8	Sequence counter
2 to 3	int16	Pressure height
4 to 5	int16	Velocity downwards
6 to 7	int16	Roll angle
8 to 9	int16	Pitch angle
10 to 11	uint16	Magnetic heading
12 to 13	uint16	Signal health information (see Section 2.4). Bits 0 to 1: pressure altitude. Bits 2 to 3: velocity downwards. Bits 4 to 5: roll angle. Bits 6 to 7: pitch angle. Bits 8 to 9: magnetic heading. Bits 10 to 15: reserved

Height in meters = $(0.16784924 * (\text{integer value}) - 1000)$.

Velocity in meters per second = $9.155413e-3 * (\text{integer value})$.

Angle in radians = $9.587526e-5 * (\text{integer value})$.

3.3 BAHRS accuracy information (0x03)

Byte position	Data type	Description
1	uint8	Sequence counter
2 to 3	uint16	Attitude standard deviation N, 0x0000 - invalid
4 to 5	uint16	Attitude standard deviation E, 0x0000 - invalid
6 to 7	uint16	Magnetic heading standard deviation, 0x0000 - invalid
8 to 15	uint64	Microcontroller time, [us]

Angle in radians = $9.587526e-5 * (\text{integer value})$.

3.4 Time of navigation data (0x04)

Byte position	Data type	Description
1	uint8	Sequence counter
2	uint8	Sequence counter of the navigation data message
3 to 10	uint64	Microcontroller time, [us], that corresponds to navigation data package with the given sequence number

When the second and the third fields contain zeros simultaneously, the data is invalid.

3.5 Time of inertial data (0x05)

Byte position	Data type	Description
1	uint8	Sequence counter
2	uint8	Sequence counter of the inertial data message
3 to 10	uint64	Microcontroller time, [us], that corresponds to inertial data package with the given sequence number

When the second and the third fields contain zeros simultaneously, the data is invalid.

3.6 Time of the latest synchronization pulse (0x06)

Byte position	Data type	Description
1	uint8	Sequence counter
2 to 9	uint64	Microcontroller time, [us]

3.7 Software version (0x0F)

Byte position	Data type	Description
1 to 3	char	Project code
4 to 5	uint16	Major software version code
6 to 7	uint16	Minor software version code

3.8 Hardware version (0x1F)

Byte position	Data type	Description
1 to 2	uint16	MCU ID
3 to 6	uint32	Unique MCU ID 1
7 to 10	uint32	Unique MCU ID 2
11 to 14	uint32	Unique MCU ID 3

4 Description of debug messages

Not included.

5 Service messages

5.1 Request to enter diagnostics mode (0xF0)

The payload is empty.

5.2 Request to exit diagnostics mode (0xF1)

The payload is empty.

5.3 Request to read NVM page (0xF2)

Byte position	Data type	Description
1	uint8	The number of the NVM page to read, from 0 to 249

Remark: as of 16.05.2023 this message type is not padded!

5.4 NVM page data (0xF3)

Byte position	Data type	Description
1	uint8	Page number, from 0 to 249

2 uint8[32] Page data

Remark: as of 16.05.2023 this message type is not padded!

5.5 Acknowledgement of diagnostics message reception (0xFF)

Byte position	Data type	Description
1	uint8	Message type to acknowledge
2	uint8	Status: 0 – OK, error codes otherwise

Remark: as of 16.05.2023 this message type is not padded!

6 Protocol versions

Document version	16-bit integer protocol version identifier
Version 0.1, 0.2, 0.3, 0.4	0x0001
Version 0.5, 1.0, 1.1	0x0002
Version 2.0	0x0003